



NOTE: INSTALL FIRST FASTENER IN LOW CLOSEST TO THE OVERLAP RIB. PROCEED WITH FASTENER EVERY OTHER LOW (12" O.C.)

PANEL SUPPORT FASTENER SPACING

ATTACHMENT DETAIL

DESIGN DETAILS

FLOLINE

ARCHITECTURAL SYSTEMS, LLC

NATIONAL SALES OFFICE
25523 RUFF STREET
PLAINFIELD, ILLINOIS 60585
(630) 922-7879
(630) 922-0880 (FAX)

ENGINEERING & DESIGN
3514 SHENANDOAH AVE
ST LOUIS, MO 63104-1724
(314) 783-0415
(314) 783-0416 (FAX)

DETAIL NAME: ATTACHMENT DETAIL	
DESIGN DETAILS	DATE: 01/11/10
DRAWN BY: ERNIE MANN	DRAWING FILE NUMBER: attach001-09 011110